

D4F or K4J or K4M or M4R

Value between the terminals 2 and 4 (Ω)	Capacity	Height H (mm \pm 6 mm)
28 \pm 11	full tank	upper stop
83 \pm 22	tank 3/4 full	144
142 \pm 23	tank 1/2 full	112
213 \pm 23	tank 1/4 full	73
287 \pm 24	reserve	39
317 \pm 7	tank empty	lower stop

Check that the resistance varies when the float is moved.

Place the sender unit on a flat surface.

H is the height between the sender unit float pivot and the flat surface.